




# PROJECTOR INSTALLATION GUIDE

## Recommended Measurements

### INSTALLATION GUIDELINE

The following chart is a guideline for installing your smart projector to achieve optimal results. These are recommended heights and dimensions for the average classroom based on grade level, but they can be customized to meet the unique layout of your room.

	Distance in Inches			
		SB660 (TEQ-Z780M)	SB680 (TEQ-Z780M)	SB685 (TEQ-750)
Elementary School	A	30"	27"	27"
	B	68½"	73½"	73½"
	C	81"	88"	91"
Middle School	A	33"	29"	29"
	B	71½"	75½"	75½"
	C	84"	90"	93"
High School	A	37"	31"	31"
	B	75½"	77½"	77½"
	C	88"	92"	95"



#### PLEASE NOTE:

If you make an adjustment to any measurement, you must increase or decrease all other measurements by the same increment.

FOR EXAMPLE: Middle School (SB660 with TEQ-Z780M Projector)

Suggested Heights:

Custom Heights:

A. 33"	(An increase of 2 inches) →	A. 35"
B. 71½"	(An increase of 2 inches) →	B. 73½"
C. 84"	(An increase of 2 inches) →	C. 86"